


### Step 1 Content and easy setup of the "BENZING Live!"

#### BENZING Live!:

The new generation of the pigeon sport has already begun. Be one of the first joining the new pigeon community.

Please follow this instruction step by step.

#### BENZING Live! Contents:




#### BENZING Live! Setup:

1. Minimum BENZING M1 software version 03.12 is required to work with the BENZING Live!
2. Connect the BENZING Live! with the connection cables between the BENZING M1 and the first antenna.
3. Connect the provided GPS receiver on the antenna plug (SMA) of the BENZING Live! device.
4. Make sure to place the GPS receiver outside of the loft to get a GPS signal.
5. The SIM card must be inside the BENZING Live!.
6. Plug-in the power supply cable at the BENZING Live!.
7. Plug-in the power supply now into the mains power socket.
8. As the BENZING Live has its own GPRS Modem built in, make sure that it's able to catch a mobile network signal.



**NOTE:** With the "Annual membership - BENZING Live", you'll be able to upload up to 250 sessions (races and trainings)! Every time you start the BENZING Live!, a session will be created. So every time you REBOOT the BENZING Live!, a new session will be created as well!




### Step 2 BENZING M1 Settings for the "BENZING Live!"

#### 1. The BENZING Live! Menu in the BENZING M1:

After all devices have been connected together, you can start up the BENZING M1 with the power supply. Afterwards you can see the BENZING logo and the installed software version on the display.


Since the software version 03.12 of the BENZING M1, there is an additional BENZING Live! menu item in the BENZING M1. You can find this, when you go into the MENU → SYSTEM → and then scroll down to the field [BENZING Live]




Select the BENZING Live menu with to get into the BENZING Live settings and information.

#### 2. Set up:

To get the BENZING Live! to work with the BENZING M1 you first have to insert your Live! credentials into the "LIVE ID" menu item.




So first of all, open the menu "LIVE ID" in the BENZING M1.



Here you have to fill in your personal BENZING Live! ID and password, which you can find on the BENZING Live! ID Card. The BENZING Live! ID Card is also inside of the box of the BENZING Live!.

With or you can choose the right characters.  
 With or place the cursor one step to the left / right.  
 [OK] (green key) – saves the entered data




After you have filled in your BENZING Live! ID, you must press "OK" and insert the password of your BENZING Live! account (the password is also on the BENZING Live! ID Card, but you can also change the password on the BENZING Live! website "www.benzing-live.com"). **Note the case-sensitivity!**


When you change the password on the homepage, please consider to change it in the BENZING M1 menu as well!

Now the necessary settings are done and the BENZING Live!, the BENZING M1 and the online loft mode server have been configured and coupled!

#### 3. Check settings:



Press the "INFO" button in the BENZING Live! menu on the BENZING M1 to get into the BENZING Live! Information menu.



The following states can be shown on the display:  
 SIM → SIM card is not inside the BENZING Live!  
 INIT → The BENZING Live! is initializing itself  
 OK → Everything is fine  
 COM ERR → Communication Error  
 1 or X → 1 = Login correct; x = Login incorrect  
 NOK → GPS no signal/ receiver not connected



#### Additional information:

If there is no mobile network available, the data of the arrived pigeon will be sent to the server as soon as the mobile network is available again!

### 1. Open up the website and login:


After doing the configuration in the BENZING M1 with the BENZING Live!, you can start your computer and open your preferred web browser. Open the website <http://www.benzing-live.com>, where you can find all your personal and transmitted data, which has been sent from the BENZING Live!.

To start with the website, press the login button on the top right side. **Please prepare your BENZING Live! ID Card!**



On the first login you need your BENZING Live! credentials, which can be found on the BENZING Live! ID Card. Your login data can be changed after the first login!

Please fill in your login data on the login window:




### 2. Confirmation of terms and conditions:


On your first login you must confirm our terms and conditions to use our features by filling in your Email address and hitting the accept button:

Accept


Email



Afterwards you'll get redirected automatically to the welcome page of our website!



### 3. Website overview:



#### My Races:

Manage all your races. There you'll be able to set the liberation time and the GPS coordinates of the liberation point as well as your loft coordinates.

#### My Trainings:

Manage all your trainings. There you'll be able to set the liberation time and the GPS coordinates of the liberation point as well as your loft coordinates.

#### My Community Flights:

Compare your flights with your friend's results, and you can see other pigeon's stats as well.

#### Time comparisons:

The BENZING Live! is high secure, it compares 3 different times to be safe:

1. GPS time
2. BENZING clock time
3. BENZING server time

With this "three time comparison", manipulations can get discovered easy.

#### My Profile:

Here you can change your name, address, email, and telephone number. Also the coordinates will be displayed, when you have done your first flight with the BENZING Live! connected!

#### Change password:

You can change your current password here. **Note:** Please also edit the password in the BENZING M1 Live! Settings, otherwise the live results will not be sent onto the servers!

### 4. Overview "My Profile":

Make sure to fill in all necessary fields before you start your first training or race. All this data needs to be accurate for the evaluation as well as for the speed calculation and further information.

#### User profile

Keep your profile always up to date!

LoftID

First name \*

Last name \*

Street

City

Zip

Email \*

Country \*

Loft Latitude \* ° ' "  Last latitude from BENZING Live: 50° 58' 26.72' N

Loft Longitude \* ° ' "  Last longitude from BENZING Live: 4° 22' 13.83' E

Language

Unit

GPS Format

Club Number  Here you can fill in your club number!

Fancier Number  Here you can fill in your fancier number!

To read more about how to get the race results and how to do an evaluation at the loft, please proceed to the BENZING Live! Evaluation @ Loft manual, which can be found in your BENZING Live! package.

You may also check if a new manual is available online at <http://www.benzing.cc>